

COMP 012 - Network Administration

Windows + Linux + Packet Tracer + Python Automation

SESSION 7: NETWORK SERVICES CONFIGURATION

ACTIVITY 7.1: DNS SERVER CONFIGURATION

Topic: Setting up DNS on Windows and Linux

Description: Configure DNS servers for name resolution in your lab

INSTRUCTIONS:

Windows DNS Server:

- Add DNS Server role in Server Manager
- Create Forward Lookup Zone: yourlab.local
- Create Reverse Lookup Zone: 192.168.1.x
- Add A records for all servers
- Add CNAME for www, mail
- Add PTR records for reverse lookup

Linux DNS (BIND9) - Optional:

- sudo apt install bind9
- Configure /etc/bind/named.conf.local
- Create zone file
- Configure forwarders

Test DNS:

- nslookup servername.yourlab.local
- nslookup [IP address] (reverse)
- From Windows: nslookup
- From Linux: dig, host commands

Configure clients to use your DNS server

Document all DNS records created

Deliverables: Submit DNS configuration and nslookup test results

30 Points

ACTIVITY 7.2: DHCP SERVER CONFIGURATION

Topic: Implementing DHCP for automatic IP assignment

Description: Set up DHCP to automatically configure network clients

INSTRUCTIONS:

Windows DHCP Server:

- Add DHCP Server role
- Authorize in Active Directory
- Create new scope:
 - Name: LAN_Scope

- Range: 192.168.1.100 - 192.168.1.200
- Subnet: 255.255.255.0
- Exclusions: 192.168.1.100-110 (for servers)
- Lease duration: 8 days

Configure scope options:

- Router (003): 192.168.1.1
- DNS Server (006): 192.168.1.10
- Domain Name (015): yourlab.local

Create reservations:

- Reserve IP for printer by MAC address

Activate scope

Test from client:

- ipconfig /release
- ipconfig /renew
- ipconfig /all (verify DHCP settings)

View leases in DHCP console

Deliverables: Submit DHCP configuration and client lease screenshots

30 Points

ACTIVITY 7.3: WEB SERVER AND FILE SHARING

Topic: Deploying IIS, Apache, and file shares

Description: Set up web servers and file sharing services

INSTRUCTIONS:

Windows IIS Web Server:

- Add Web Server (IIS) role
- Create test website in C:\inetpub\wwwroot
- Create HTML page with your name
- Test: http://localhost
- Configure binding for yourlab.local

Linux Apache Web Server:

- sudo apt install apache2
- Create page in /var/www/html
- sudo systemctl enable apache2
- Test: http://[linux-ip]

Windows File Sharing (SMB):

- Create folder C:\Shares\Public
- Right-click → Properties → Sharing
- Set share and NTFS permissions
- Access: \\servername\Public

Linux File Sharing (Samba):

- sudo apt install samba

- Configure `/etc/samba/smb.conf`
 - Create Samba user: `sudo smbpasswd -a user`
 - Test from Windows: `\\linux-ip\sharename`
- Document all services and access methods

Deliverables: Submit web server and file share configuration with access tests

35 Points

TOTAL POINTS: 95